

INSTALLATION GUIDE

Self Adhesive Wallpaper

Please refer to the Installation Instructions supplied with your Printamural Wallpaper. These instructions include a visual layout of your mural and indicate the Wallpaper 'drops' to be installed. Please take time to review these instructions before you start your installation.

Take particular care to understand the sequential arrangement and orientation of all the 'drops'.

We suggest that the installation be carried out by two people.

Normally the Wallpaper is supplied ready for 'overlap' installation, rather than for 'butt joint' installation, to ensure the best possible alignment of the 'drops' on the wall.

Each 'drop' is 50mm oversize at the top and bottom edges, and the first and last 'drops' are 50mm oversize to left and right correspondingly to allow for trimming of the mural to fit any irregularities in the wall edges and corners. The inner 'drops' all have a 2.5mm overlap bleed on both edges. This overlap is NOT cut back after installation.

Instructions for 'Overlap' Installation of Self-Adhesive Wallpaper

It is essential that the wall surface is perfectly flat. Ensure that the wall surface is suitably prepared, sound and dry.

The tools you might need include; pencil, tape measure, plumb line, straight edge, spirit level, wallpaper smoothing brush or foam roller, damp cloth and/or sponge, wallpaper scissors, Stanley knife.

Work in sequence, one 'drop' at a time. Each 'drop' is numbered on the reverse side at the top.

1. Carefully unpack your Wallpaper and lay the 'drops' out in sequential order. The 'drops' are supplied in equal widths.

2. It is essential to establish the correct vertical setting out line on the wall. Firstly, measure the width of the first 'drop' and subtract 50mm (for the excess bleed). This is the distance of the vertical

setting out line from the left hand edge of the wall. Now draw the vertical line at the correct distance from the wall edge, using a pencil. Use a plumb line and straight edge to ensure the line is vertical and straight.

**** NOTE** In certain circumstances (for example, if your floor or walls are not level) you might find it preferable to align the mural horizontally rather than vertically to the top of a piece of prominent furniture, such as a sideboard, that may exist in front of the wall. Determine a horizontal line to 'set out' against and use a spirit level to adjust the vertical 'setting out' line to be at right angles to the horizontal.

3. Hang the first 'drop'. Use your vertical line to ensure that the 'drop' is vertical on the right hand side. Start from the top, peeling away the backing paper as you work downwards. Use a wallpaper foam roller or damp cloth to carefully smooth the Wallpaper down flat and remove any air bubbles. You can lift and reposition the 'drop' if necessary.

4. Now hang each 'drop' in sequential order, ensuring each 'drop' overlaps the previous one by 5mm and that the mural image is aligned correctly. Smooth the wallpaper down flat as before.

5. When all the 'drops' have been applied all the outer edges can be trimmed to fit using scissors or sharp knife. Take care not to stretch or tear the Wallpaper. Trim around light switches and sockets in a similar way.

Printamural Limited

T 01827 383936
E studio@printamural.com
W www.printamural.com

SAW 0662/0610